



THE XCELPLUS 4 STEP ENGINE CARE SYSTEM

1

SLUDGE OUT
(if required)

and change oil.



2

RING FREE


Add Ring Free
and leave till
next oil change.



3

**ENGINE
TREATMENT**

Add Engine
Treatment to
next oil change.



4

**UPPER CYLINDER
TREATMENT**

Add Upper
Cylinder Treatment
to fuel.



Distributed by: MC1

7 Boyle Court
Sunshine West, Victoria, Australia, 3020

+61 3 8683 5660

xcelplus.com.au